INSTALLATION INSTRUCTIONS SLIDE BAR ASSEMBLY MODEL NO. 292

NWP-292

(949) 417-5207 Santa Ana, Ca. 92705 www.brasstech.com

10/10/2011

Recommended Installation by a Professional Plumbing Contractor

Locate the desired position of slide bar on finished wall. See Fig. 1.

Mark wall and drill 5/16" hole for WALL ANCHORS (1) to dimension shown in Figure 1.

Place SLIDE BAR (2) into END POST (3). Note: Large diameter hole in SLIDE BAR (2) must face out as shown in Figure 2.

Place POST (3) onto ESCUTCHEON (4), insert SCREW (5) & securely tighten into ANCHOR (1) as shown in Figure 2.

Press END CAP (6) into end of POST (3).

Slide and lock HOLDER ASSEMBLY (7) onto SLIDE BAR (2) and repeat the above steps to the other end of SLIDE BAR (2) as shown in Figure 3.





