



<p>Record your model number.</p> <p>NOTICE: Adequate floor support is required. A wood support must be a minimum of 2" (51 mm) thick by 6" (152 mm) wide. Standard 2x6 lumber is NOT sufficient for this application. NOTE: Concrete can be used as the floor support. Observe all local plumbing and building codes.</p>	<p>1 Roughing-In</p>	<p>2 Roughing-In</p>	<p>3 Construct a wood support under the floor according to the roughing-in dimensions.</p>	
<p>4 Verify correct spout orientation before installing the base. The base has a notch on the cold supply side.</p>	<p>5 Use the base to mark the mounting holes on the wood support.</p>	<p>6 Using a 3/16" drill bit (provided), drill 1-1/2" (38 mm) deep holes at the marked locations. Use a masonry bit if drilling into concrete.</p>	<p>7 Install the base to the support with the screws and washers.</p>	<p>8 Apply sealant tape to the supply pipes. Thread the pipes into the base, with the cold supply on the notched side. Turn on the water and check for leaks.</p>
<p>9 Turn off the water and install the guard to the base.</p>	<p>10 Finish the floor, leaving a 3-1/4" (83 mm) oval hole to fit the guard. Fit the finished floor between the MIN and MAX lines, and no more than 1/4" (6 mm) from the guard.</p>	<p>11 Trim the guard flush with the finished floor.</p>		

Questions? Problems? For additional assistance, please contact
KALLISTA's Customer Service Department at 1-888-4-KALLISTA
(1-888-452-5547) or kallista.com.